


Garment size chart

Measurement	2XS	XS	S	M	L	XL	2XL	3XL		Tolerance
A Chest below arm hole	17	18.5	20	21	23	24.5	26	27.5		0.5
B Length (Neck point on shoulder to hem)	24	26	28	29	30	31	32	33		0.5
C Across shoulder	17	18.5	20	21.5	23	24.5	26	27.5		0.5
D Sleeve overarm	7.5	8	8.5	8	9.5	10	10.5	11		0.5
E Armhole opening	8	8.5	9	9.5	10	10.5	11	11.5		0.5
F Sleeve cuff opening	5	5.5	6	6	6.5	6.5	7	7		0.5
G Placket length	7	7	7	7	7	7	7	7		0.125
H Placket width	1.4	1.4	1.4	1.4	1.4	1.4	1.4	1.4		0.125
I Neck drop	2.75	2.75	2.75	2.75	2.75	2.75	2.75	2.75		0.5
J Hem	1	1	1	1	1	1	1	1		0.125
K Collar width	2.75	2.75	2.75	2.75	2.75	2.75	2.75	2.75		0.125
L Neck joining	6	7	8	8	8	8	8	8.5		0.5
M Half moon length	3.5	3.5	3.5	3.5	3.5	3.5	3.5	3.5		0.5
N Half moon width	7.75	8.75	9.75	9.75	9.75	10	10	10		0.5
O Collar length	15	15	16	16	17	17	18	18		0.5
J Inside label	4	4	4	4	4	4	4	4		0.125

1. All sizes are in inches except marked 2. All size of garments must be within tolerance limit

Garment markings



 01803 834266

 sales@eurosafeltd.uk

 Visit us online at eurosafeltd.uk

 Eurosafelimited
8a Hauley Road
Dartmouth
TQ6 9AA