


Garment size chart

Measurement	XS	S	M	L	XL	2XL	3XL	4XL	5XL	Tolerance
A 1/2 chest	50	52	54	56	58	60	65	67	69	+/-1.0
B Body length from HPS	68	70	72	74	76	78	80	82	84	+/-1.0
C 1/2 armhole	24	25	26	27	28	29	32	33	34	+/-1.0
D Shoulder	12	13	14	15	16	17	19	20	21	+/-1.0
E Sleeve length inc cuff	56	58	60	62	63	64	64	65	66	+/-0.5
F Rib border and cuff width	5	5	5	5	5	5	5	5	5	+/-0.5
G Rib neck width	3	3	3	3	3	3	3	3	3	+/-0.5
H Bottom width relax	39	40	42	44	46	48	52	54	56	+/-0.5
I Sleeve opening relax	9	9	10	10	10	11	11	12	12	+/-0.25
J Sleeve opening stretched	14.5	14.5	15	15	15	16	16	17	17	+/-1.0
K Neck opening	20	20	20	20	20	20	20	20	20	+/-1.0
L Front neck drop	9	9	9	9	9	9	9	9	9	+/-0.5

1. All sizes are in inches except marked 2. All size of garments must be within tolerance limit

Garment markings



 01803 834266

 sales@eurosafeltd.uk

 Visit us online at eurosafeltd.uk

 Eurosafelimited
8a Hauley Road
Dartmouth
TQ6 9AA