

## Filter Fitting Instructions



The **Sentinel** filter range offers protection against hazardous gas, vapour and particulates within a wide variety of industries. Fully compatible with the Sentinel Full Face and Half Mask, the ergonomic filters offer incredibly low breathing resistance with optimised volume.

### Alpha Sentinel filters

Combine with the Alpha Solway Sentinel Full Face Mask and Half Mask

ASRAS0003BF	P3S
ASRAS0003BH	P3H
ASRAS0004BZ	P3P
ASRAS0005BZ	A1
ASRAS0006BZ	A2
ASRAS0007BZ	ABEK1

[Use the Alpha Sentinel filter cover to attach P3P filters A1, A2, ABEK1]



**DESIGNED  
& MADE IN  
THE UK**

### BEFORE USE

Only use the filter if the packaging is undamaged before first use and check the filter is clean and undamaged. Replace the filter if it is damaged and check the marking on the filter to ensure it is within a usable period. The filter type and class are marked on the filter. Ensure the correct filter is used, once the environment and contamination is known.

### USE

For use only with approved Alpha Solway respiratory face-pieces (Alpha Solway FFM or Alpha Solway HM); refer also to face-piece user instructions (Alpha Solway FFM or Alpha Solway HM). Two filters must be used at the same time; these must be the same type and class.

### ATTACHING FILTERS TO A MASK

1. Check the integrity of the mask connector (seal on the full face mask or mask surface on the half mask); if worn away or damaged, replace the seal/mask, as appropriate.
2. Push the filter onto the mask connector, with the tabs on the filter connector aligning with the respective tabs on the filter body [see Diagram 1].
3. Rotate the filter clockwise until the filter clicks into place [see Diagram 2].
4. Make sure the filter is correctly seated [see Diagrams 3 and 4].

## Filter Fitting Instructions



### COMBINATION FILTERS

1. To assemble combination gas, vapour and particulate filters, insert the Particulate P3-P filter into the filter retaining cover as shown; marking should be visible once fitted to the filter [see Diagram 5].
2. Push the gas filter body into the retaining cover, ensuring a correct fit. Ensure all retaining cover clips are firmly in place on the gas filter [see Diagram 6].
3. Assemble the filter body onto the mask, as described in these instructions, as normal [see Diagram 7].



### REMOVING THE FILTERS FROM THE MASK

1. Rotate the filter anticlockwise until loose.
2. Lift the filter away from the mask.

